SAFETY WARNINGS

OLIGHT

PLEASE READ THIS DOCUMENT CAREFULLY BEFORE USE AND KEEP IT FOR FUTURE REFERENCE!

(WARNINGS OBBI)

B

CONTENTS

(EN) English 01
(CN) 简体中文 03
(FI) Finnish 05
(NO) Norwegian 08
(SV) Swedish 10
(NL) Nederlands 13
(DE) Deutsch 18
(HU) Magyarország 23
(RU) Русский 24
(ES) Español 27
(RO) Romanesc 30
(UA) Ukrainian 33
(JP) 日本語 37
(KR) 한국어 43
(FR) Français 46
(IT) Italiano 49
(SK) Slovenskýjazyk 52
(PT) Português 55

(EN) English

WARNING

- Do not place the product near a fire or heat source, or throw the product into a fire.

CAUTION

- Do not look directly at the light source or shine the eyes, because it may cause temporary blindness or damage to the retina in severe cases.
- Do not charge the light with any other non-specified chargers.
- Do not store the product in a car or places where the temperature may exceed 60°C, because it may deform or damage the product.
- Please do not disassemble or modify the battery, or use the battery for other purposes.

NOTICE

- Non-pet toy.
- Do not disassemble the product.
- Do not immerse the product in seawater or other corrosive media as it will damage the product.
- When the product gets hot, please switch it to low brightness mode, or turn it off temporarily.
- Active thermal protection: The built-in sensor monitors the temperature in real time. It prevents overheating by reducing the output (Part of products).
- In the environment where the temperature is below 0°C, the product only works in low brightness.
- The battery has a high temperature protection function. When working in a high temperature environment (> 40 °C), the battery will stop charging.
- Do not short-circuit the charging port with the metallic objects.
- Do not put it in the sewage, as it leads to the risk of corrosion, leakage of the charging port can cause discomfort.
- If water enters the charging port, it will cause charging failure. Please put it face down to dry it, or with a hot dryer.
- Keep the charging port clean and dry.
- The tail switch is magnetic, and the metal powder adsorbed on the surface will affect the function, please clean it immediately.

01

- Do not place the light in a dusty environment, dust may enter the switch and cause it to malfunction. (Part of products)
- It is built-in with the lithium battery, please do not drop off it or hit it with heavy objects.
- Do not act as a bell, because it may cause damage to the product.
- Not as a baby toy.
- Avoid contacting with sharp objects in case of scratches and damage to the product.
- Do not soak the product in water, because it may damage the product.(Part of products)
- Only two large size Cells should be charged on the Omnis at a time.
- The product can be charged with an MCC3 charging cable, but the charging indicator may not work properly if doing so.(Part of products)
- While the network data is shared among different phones, the host is only one device online in the mesh network, the device can only be controlled by the mobile phone firstly searching and adding it. If you want to control the device by different phones, please disconnect one and use the other phone to search and add it.(Only Duo Pro)
- While the network data is shared among different phones, the app will not synchronize the new data and preferences after sharing. If you want to synchronize the data, please reshare the data by a new QR code.(Only Duo Pro)
- OTA upgrade is only available for Android phones.(Only Duo Pro)
- When the APP imports network data from a QR code, the original data in the APP will be overwritten.(Only Duo Pro)
- Frequent operation or multi-device control may lead to data congestion and cause the APP to response slowly or no response at all. Please try to operate it after a few minutes.
- Do not short-circuit the charging port with the metallic objects.
- Do not put it in the sewage, as it leads to the risk of corrosion, leakage of the charging port can cause discomfort.
- If water enters the charging port, it will cause charging failure. Please put it face down to dry it, or with a hot dryer.
- Keep the charging port clean and dry.
- The tail switch is magnetic, and the metal powder adsorbed on the surface will affect the function, please clean it immediately.

02

- Не располагайте свет в пыльной среде, пыль может попасть в переключатель и вызвать сбой в работе.(Часть продуктов)
- Встроенный литиевый аккумулятор, не роняйте его и не ударяйте по нему тяжелыми предметами.
- Не используйте как колокольчик, это может повредить продукт.
- Не как детская игрушка.
- Избегайте контакта с острыми предметами, во избежание появления царапин и повреждения продукта.
- Не погружайте продукт в воду, это может привести к его повреждению.(Часть продуктов)
- На Omnis одновременно можно заряжать только два больших Omnis.

03

- 本品を火源や発熱源の近くに置かないでください。また、本品を火の中に投げ入れないでください。
- 光源を直視しないでください。また、光源を目に照らさないでください。重症の場合、一時的な失明や網膜の損傷や破損を引き起こす可能性があります。
- 他の非指定の充電器でライトを充電しないでください。
- 本品を車内や、温度が60℃を超える可能性のある場所に保管しないでください。変形や破損の原因となります。
- 電池を分解したり改造したりしないでください。また、電池を他の目的で使用しないでください。

注意

- 本品はペット用玩具ではありません。
- 本品を分解しないでください。
- 本品を海水やその他の腐食性の媒体に浸漬しないでください。製品が破損する恐れがあります。
- 製品が熱くなった場合は、低輝度に変更するか、または電源を切ってください。
- 温度保護：内蔵のセンサーがリアルタイムで温度を監視します。出力を減らすことで過熱を防止します。(一部の製品)
- 0℃以下の環境では、低輝度のみ使用可能です。
- 本品は、リチウム電池を内蔵しており、充電温度は（40℃以上）で使用すると、充電に失敗することがあります。
- 充電ポートに水が入ると充電不良の原因になります。水が入った場合には、下向きに置くか温風で乾かす、または自然乾燥してください。
- 充電ポートは清潔で乾燥した状態に保ってください。
- テールスイッチは磁気スイッチで、表面に金属粉を吸着した場合機能に影響を与えますのですぐに取り除いてください。
- ほこりの多い環境にライトを置かないでください。ほこりがスイッチに入り、機能障害を引き起こす原因となります。(一部の製品)
- リチウム電池を内蔵しております。高い所からの落下や重いものとの衝突を避けてください。
- 製品の故障や損傷を防ぐために、説明書に記載されたもの以外の充電器を使用しないでください。
- 電池を分解、改造したり、他の用途に使用しないでください。

注意

- ペットのおもちゃではありません。
- 本文や破損を防ぐために、説明もののの使用をお勧めします。
- 破損につながるおそれがありますので、製品を水中に浸さないでください。(一部の製品)
- 加熱などの異常な際い場合は電源を切ってください。製品が破損する恐れがあります。
- 製品が熱くなった場合は、低輝度に変更するか、または電源を切ってください。
- 温度保護：内蔵のセンサーがリアルタイムで温度を監視します。出力を減らすことで過熱を防止します。(一部の製品)
- 気温が0℃以下の環境では、低輝度のみ使用可能です。
- リチウムイオン充電池が内蔵され