


OOLIGHT USER MANUAL



Parameter	Specification
Charging cable	USB magnetic charging cable, length: 1.5m
Input	USA A - Type DC 5V 1A
Charging pattern	CC&CV
Maximum charging current	1A
Voltage of fully charged battery	4.2V±0.05V
Time to fully charge	2 hours (for reference only. If the USB power source is insufficient to provide 5V 1A power, the charging time will be longer)
Charging indicator	Red: charging Green: full (battery >=95%) or disconnected with flashlight
Time to fully charge	2 hours (for reference only. If the USB power source is insufficient to provide 5V 1A power, the charging time will be longer)

Specifications
TURBO 1000 lumens 100m 110mm
HIGH 300 lumens 120m 105mm
MED LOW 60 lumens 100m 100mm
0.1110" (2.825") Max 0.41.33" (10.610") Dia 0.98" (25.150") H
3.07W (17g) Rechargeable Battery
Max Output: 0.25W (Class1) Working temperature: Wavelength: 510-530nm 6-8°C

PRODUCT OVERVIEW
Selector Battery Indicators Center Button Magnetic Charging Port Green Laser White Light

* All above specifications are test results based on ANSI/NEMA FL1209 Standard. The tests are performed using the battery included in the product with full battery. Note: The maximum output brightness will decrease as the battery voltage decreases.

Arkfeld

Thank you for purchasing this Olight Product. Please read this manual carefully before use and keep it for future reference!

IN THE BOX

BEFORE FIRST USE

CHARGING

BATTERY LEVEL INDICATORS

WHIT LIGHT MODUS

LASER

OPERATION

WARNING

CAUTION

REMARK

EXCLUSION CLAUSE

NOTICE

HOW TO OPERATE

WHITE LIGHT MODE

BRIGHTNESS ADJUSTMENT

MOONLIGHT MODE

DIRECT ACCESS TO TURBO MODE

STROBE

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

HOW TO OPERATE

WHITE LIGHT MODE

BRIGHTNESS ADJUSTMENT

MOONLIGHT MODE

DIRECT ACCESS TO TURBO MODE

STROBE

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

HOW TO OPERATE

WHITE LIGHT MODE

BRIGHTNESS ADJUSTMENT

MOONLIGHT MODE

DIRECT ACCESS TO TURBO MODE

STROBE

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

HOW TO OPERATE

WHITE LIGHT MODE

BRIGHTNESS ADJUSTMENT

MOONLIGHT MODE

DIRECT ACCESS TO TURBO MODE

STROBE

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

HOW TO OPERATE

WHITE LIGHT MODE

BRIGHTNESS ADJUSTMENT

MOONLIGHT MODE

DIRECT ACCESS TO TURBO MODE

STROBE

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

HOW TO OPERATE

WHITE LIGHT MODE

BRIGHTNESS ADJUSTMENT

MOONLIGHT MODE

DIRECT ACCESS TO TURBO MODE

STROBE

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN

FLASHLIGHT WITH RETURN